

Areas of application: Soil and asphalt compaction, trench and pipeline construction, backfilling, foundations and repair work on asphalt.







Areas of application: Soil and asphalt compaction, paving work. Repair work in road and pavement construction. trenches and landscaping.

weight

BP 10/35

BP 12/40

BP 12/50 A*

BP 20/50

BP 20/50 D

BP 25/50

BP 25/50 D

BVP 10/30

BVP 10/36

BVP 18/45

BVP 18/45 D

BP 10/36 e

BP 18/45 e

BVP 12/50 A*

(CECE) kg

82

109

108

72

104

width

500

500

500

500

500

300

360

500

450

450


450

450



Asynchronous motor







Areas of application: Soil and asphalt compaction, block paving, paths, roads and rail tracks, backfills, trench and sewer construction, landscaping, foundation construction.



| | weight (CECE) kg | width mm | manufacturer |
|--|--|---|---|
| PR 25/40 PR 25/40 D PR 25/50 PR 25/50 D PR 35/42 PR 35/42 D PR 35/60 D PR 45/45 PR 45/45 PR 45/55 D PR 50/65 D PR 60/65 PR 60/65 D PR 100/80 D PR 100/80 D | 135 150 140 155 190 210 205 225 260 340 400 405 455 420 460 580 700 750 | 400 400 500 500 420 420 600 600 600 450 550 650 650 650 650 800 800 | Honda Hatz Honda Hatz Honda Hatz Honda Hatz Honda Hatz Honda Kohler Hatz Kohler Honda Hatz Hatz Kohler Honda Hatz Hatz Hatz Hatz Hatz Hatz Hatz |



Areas of application: block paving. Concrete blocks, natural stones (cut/diamond sawn), chamferless stones, large formats, sensitive surfaces and stone formats, large areas, reduction of damage to property.

Operating

weight (CECE) kg

228

248

477

BPR 25/50 D

BPR 35/60

BPR 35/60 D

BPR 50/55 D

BPR 55/65 D

BPR 60/65



| | P |
|------------------------|------------------------|
| Working width mm | Engine manufacturer |
| | |
| 530 | Hatz |
| 630 | Honda |
| 630 | Hatz |
| 680 | Hatz |
| 680 | Kohler |
| 680 | Honda |
| 680 | Hatz |



Areas of application: Soil and asphalt compaction. New construction and repair of pavements, verges, cycle paths, driveway and garage entrances, children's playgrounds, tennis courts and sports fields as well as construction of farm and forest





Areas of application: Soil compaction. Trench and pipeline construction, backfilling and foundation work - wherever high demands are placed on mobility, manoeuvrability and ease of operation coupled with difficult ground



| | The state of the s | | | | |
|-----------|--|------------------------|---------------------|--|--|
| Туре | Operating weight (CECE) kg | Working width mm | Engine manufacturer | | |
| BMP 8500* | 1595 | 610/850 | Kubota/Kohler | | |

*Standard with combination cable/wireless control

Machines may be shown with optional accessories.

The company:

BOMAG is the global leader in the field of compaction technology. The company, which has its HQ in Boppard and has belonged to the FAYAT group since 2005, produces machines for soil, asphalt, and refuse compaction as well as stabilizers/recyclers, milling machines and pavers.

The company has six branches in Germany and 12 independent subsidiaries. Over 400 dealers in more than 150 countries guarantee the global distribution of BOMAG machines and their maintenance.

www.bomag.com

- BOMAG. Hellerwald, 56154 Boppard, GERMANY, phone: +49 (0)6742 100-0. email: info@bomag.com, www.bomag.com
- BOMAG Maschinenhandelsgesellschaft m.b.H., Klausenweg 654, 2534 Alland, AUSTRIA,
- phone: +43 (0)2258 20202, email: austria@bomag.com
- BOMAG MARINI EQUIPAMENTOS LTDA., Avenida Clemente Cifali, 530, Distrito Industrial Ritter, Cachoeirinha – RS, BRAZIL, ZIP code 94935-225
- phone: +55 (0)51 2125-6642, email: brasil@bomag.com
- BOMAG (CANADA), INC., 2233 Argentia Road, East Tower, Suites 302, L5N 2X7,
- Mississauga, ON, CANADA, phone: +1 800 782 6624, email: canada@bomag.com BOMAG (CHANGZHOU) Construction Machinery Co. Ltd., No. 66 Bopa Road,
- Xuejia Town, Xinbei District, Changzhou 213125, CHINA, phone: +86 (0)21 336 555 66, email: china@bomag.com BOMAG India Pvt Ltd, Unit No 614, B Wing, 6th Floor, Kanakia Wall Street,
- Chakala Andheri Kurla Road Andheri East, Mumbai 400 093 Maharashtra, INDIA, phone: +91 (0)865 749 2418, email: india@bomag.com
- BOMAG FRANCE S.A.S., 2, Avenue du Général de Gaulle, 91170 Viry-Châtillon, FRANCE, phone: +33 (0)1 695 786 00, email: france@bomag.com
- BOMAG (GREAT BRITAIN), LTD., Sheldon Way, Larkfield, Aylesford, Kent ME20 6SE, GREAT BRITAIN, phone: +44 (0)1622 716 611, email: gb@bomag.com
- BOMAG Italia, Via Roma 50, 48011 Alfonsine, ITALY, phone: +39 0544 864 235, email: italy@bomag.com

email: usa@bomag.com

- FAYAT BOMAG Polska Sp. z o.o., Ul. Szyszkowa 52, 02-285 Warszawa, POLAND,
- phone: +48 (0)22 482 0400, email: poland@bomag.com • FAYAT BOMAG RUS 000, 141400, RF, Moscow region, Khimki, Klayazma block, h. 1-g, RUSSIA,
- phone: +7 (495) 287 9290, email: russia@bomag.com BOMAG APAC PTE LTD, 300 Beach Road, The Concourse, #18-06, Singapore 199555, SINGAPORE,
- phone: +65 294 1277, email: singapore@bomag.com • BOMAG Americas, Inc., 125 Blue Granite Parkway, Ridgeway SC 29130, U.S.A., phone: +1 (0)803 337 0700,

*Special plate for asphalt construction *Remote control, hydraulic drive Guide bar middle position

easily in corners and up to walls. BP 12/50 A, BP 20/50, BP 25/50.

The middle position is an alternative to the stan-

dard position of the guide bar and increases the

machine's manoeuvrability allowing it to work

warranty cover!

3-2-1 warranty as standard When you offer high quality, you can also provide extensive



PRODUCT OVERVIEW

LIGHT EQUIPMENT.



Vibratory plates

Water spraying system for asphalt work

The water spraying system distributes the water evenly across the entire working width and prevent asphalt from sticking to the base plate. For BPR 25/40, BPR 25/40 D, BPR 25/50, BPR 25/50 D and all single direction vibratory plates except BVP 10/30.

The machine's HAV values are below 2.5 m/s2.

Regulation-compliant, fatigue-free working.

For all BPs and BVPs except for BVP 12/50 A

Simplified risk assessment.



Transport wheels

10/30 BVP 12/50 A).

for all single direction and reversible vibratory

Facilitate the manual transport of a vibratory plate even on rough and loose ground. Punctureproof tyres. For all vibratory plates <300 kg (except BVP



Hand-quided vibratory rollers

Cleaning rod

Rod and holder for quick and easy cleaning of scrapers and spray tubes. For BW 65 and BW 65 D.



Light Equipment

Contain all necessary parts required for servicing and maintaining the machines. Simple and reliable ordering of all the parts



Machine painted according to desired specifi-



Special paint finish



Displays degree of compaction in real time. Saves time and costs by avoiding unnecessary passes and always achieving optimum compaction. Warns of over-compaction and grain breakage and identifies weak points in the soil. BPR >350 kg, BMP 8500.



Electric starter with warning buzzer For comfortable starting of the machine. Available for the following reversible vibratory BPR 35/42 D, BPR 35/60 D, BPR 40/60 D. Electric starter as BPR series > 350 kg.

Flexible working widths thanks to replaceable extension plates

Flexible working widths thanks to replaceable extension plates.

Suitable working widths for every application ranging from small trenches to large surface


For reversible vibratory plates > 350 kg. Not for BPH 80/65 S.



Sturdy and convenient remote control.



Standard on BMP 8500, BPH 80/65 S.



For operating battery-powered machines. Vibration-resistant design, tool-free installation and full compaction performance at the touch of **Battery variants:**

Standard charger (charging time <4 h) Quick charger (charging time <2 h)

trenches (e.g. mini-trenching).

Tamper

for the padfoot.

*incl. side protection

Different padfoot widths

Suitable working widths for flexible applications

Optional side guards as additional wear protection

ranging from narrow trenches to large surface


160*, 200*, 230, 240*, 280, 290* and 330* mm

Operator needn't stand in the trench. 150 x 120 mm (w x h)

100 x 370 mm (w x h) 150 x 370 mm (w x h)

Padfoot extensions

Flexible operation when working in deep, narrow





Easy-to-mount Vulkolan mat for paving work. For effective use of the vibratory plate in paving

Protects the paving stones, prevents marks and reduces the risk of breakage. Not for BPH 80/65 S. BPR 100/80 D. BP 12/50 A and BVP 12/50 A.



Steering with either hand at all times.

Full control of the machine by reversing direction with one thumb and safety switch. With integrated city mode. BPR 70/70 D, BPR 100/80 D.



Batteries and chargers

eP 20 (20 Ah) eP 28 (28 Ah)



| ype | 3 years for | 2 years for | 1 year |
|--|--|--|-------------------|
| T amper | Spring and guide unit | Combustion engine electric motor / rechargeable batteries | Standard warranty |
| P/BVP ingle direction bratory plates | Exciter gears | Combustion engine | Standard warranty |
| PR eversible vibratory lates | Exciter gears + hydraulic travel lever control | Combustion engine | Standard warranty |
| | | | |

Exciter gears + Combustion engine Standard warranty Combustion engine Standard warranty clutch + vibration drive

Exciter gears + vibration motor/pump + compactor

BOMAG warranty conditions apply.



BOMAGFAYAT GROUP





